

## Colourline Care & Cleaning

### Daily Cleaning

A frequent cleaning raises the life span of the product. Please use a mild soap solution and a soft, lint-free cloth or a hand brush. Remove heavy stains immediately. The use of plastic cleaners is not recommended.

### Special Cleaning Problems

We recommend the following steps for removing stains from the Delius Colourline artificial leather. Many stubborn stains can be removed if you follow the following cleaning steps in the right order.

#### Cleaning Method 1

Use a mild soap solution and a soft, lint-free cloth or a hand brush. Then clean the treated area with fresh water and dry with a soft cloth.

#### Cleaning Method 2

Apply a solvent-based cleaner with a soft cloth or sponge to the stain. Then clean the treated area with fresh water and dry with a soft cloth.

#### Cleaning Method 3

Apply a highly concentrated solvent-based cleaner diluted with water (70% water, 30% acetone) with a soft cloth or sponge on the stain. The stain should disappear after less than six rubs, otherwise the stain is fixed on the surface and probably is not removable. Clean the treated area with fresh water and dry with a soft cloth.

The recommended cleaners used in cleaning method 1+2+3 are progressively more aggressive. Often, it is better to begin with the least aggressive cleaner and move to the next strongest only if the stain remains.

Source of stain	Method 1	Method 2	Method 3
spray paint	💧	💧	💧
ballpoint pen	💧	💧	💧
felt-tip marker	💧	💧	💧
lipstick	💧	💧	💧
mustard	💧	💧	💧
nicotine	💧	💧	
grease	💧	💧	
crayon	💧	💧	
eye shadow	💧	💧	
carotin	💧		
coffee	💧		
tea	💧		
blood	💧		
urine	💧		
grape juice	💧		
olive oil	💧		
motor oil	💧		
chocolate	💧		
ketchup	💧		

## Disinfectant recommendation Colourline

<b>Manufacturer</b>	<b>Disinfectant</b>
Antiseptica	Antiseptica Flächen-Desinfektion 7
	Biguacid plus
B.Braun Melsungen AG	Melsept
	Melsitt
	Hexaquart
Bode Chemie GmbH & Co.	Kohrsolin
	Dismozon pur
	Perform
	Bacillocid Spezial
Desomed AG	Desomed A 2000
	Desomed Rapid AF
	Desomed Perfekt
Dr. Schumacher GmbH	Biguanid-Fläche
	Decosept AF
Lysoform	Amocid
	Lysoform
	Lysoformin
	Lysoformin 2000
Schülke & Mayr GmbH	Gevisol
	Perform

Please make sure to read the data by the manufacturer.

This list gives a general survey of suitable disinfectants for Colourline artificial leather.

As we have no influence on the possible change of ingredients or usage, the Delius GmbH assures no liability and gives no guarantees.